

## LinkSys – PAP2 / PAP2T Auto Configuration

1. Open your web browser and navigate to the URL;  
<http://<LinksysPAPIP>/admin/advanced>

Refer tip no.1 at the end of the manual on how to find the device IP

2. Go to "Provisioning", and configure it to look as displayed below:

**LINKSYS®**  
A Division of Cisco Systems, Inc. Firmware Version: 5.1.3(LS)

**Voice** PAP2

Phone Adapter with 2 Ports for Voice-Over-IP

Info System SIP **Provisioning** Regional Line 1 Line 2 User 1 User 2

Advanced View (switch to basic view) User Login

**Configuration Profile**

Provision Enable:	<input type="text" value="yes"/>	Resync On Reset:	<input type="text" value="yes"/>
Resync Random Delay:	<input type="text" value="2"/>	Resync Periodic:	<input type="text" value="1800"/>
Resync Error Retry Delay:	<input type="text" value="3600"/>	Forced Resync Delay:	<input type="text" value="14400"/>
Resync From SIP:	<input type="text" value="yes"/>	Resync After Upgrade Attempt:	<input type="text" value="yes"/>
Resync Trigger 1:	<input type="text"/>		
Resync Trigger 2:	<input type="text"/>		
Resync Fails On FNF:	<input type="text" value="no"/>		
Profile Rule:	<input type="text" value="tftp://66.235.164.7:69/pap2all.cfg"/>		
Profile Rule B:	<input type="text"/>		
Profile Rule C:	<input type="text"/>		
Profile Rule D:	<input type="text"/>		
Log Resync Request Msg:	<input type="text" value="\$PN \$MAC -- Requesting resync \$SCHEME://\$SERVIP:"/>		
Log Resync Success Msg:	<input type="text" value="\$PN \$MAC -- Successful resync \$SCHEME://\$SERVIP:"/>		
Log Resync Failure Msg:	<input type="text" value="\$PN \$MAC -- Resync failed: \$ERR"/>		
Report Rule:	<input type="text"/>		

**Firmware Upgrade**

Copy and Paste the URL to the Profile Rule `tftp://66.235.164.7:69/pap2all.cfg`

## LinkSys – PAP2 / PAP2T Auto Configuration

3. Then Go to “LINE 1”, and configure only the User Account and Password as displayed below:

LINKSYS®  
A Division of Cisco Systems, Inc. Firmware Version: 5.1.3(LS)

Phone Adapter with 2 Ports for Voice-Over-IP PAP2

Voice

Info System SIP Provisioning Regional Line 1 Line 2 User 1 User 2

Advanced View (switch to basic view) User Login

Subscriber Information

Display Name:

Password:

Auth ID:

Mini Certificate:

SRTP Private Key:

User ID:

Use Auth ID:

4. Configure “Line 2” as well, but use a unique UserID and Password

**Warning:** Use separate accounts in Line1 and Line2 of the device. Using the same account may result in problems like, false billing, one way audio, call disconnections, etc.

5. Now press “Save Settings” button. Device would restart and you’ll be ready to call!

If you experience any problem with configurations, please do feel free to call for technical support, and we’ll be very glad to assist you.

## LinkSys – PAP2 / PAP2T Auto Configuration

---

### **PAP2 Tips,**

- 1. Getting to know the device IP,  
Lift the handset and press \*\*\*\* (Star key) four times. This will take you to the configuration menu.  
Now press 110#  
It will announce the device IP now**
- 2. How to reset the PAP2,  
Lift the handset and press \*\*\*\* to enter the configuration menu.  
Now press 73738# and then press 1 to confirm.  
Now the device will reset and you can reconfigure according to the manual.**

Thank you !!!